

High-Tensile, Tools
Posts, Gates, Electric
Rotational Grazing
Horse Fence

1-800-KENCOVE
344 Kendall Rd.
Blairsville, PA 15717

HOTCOTE™ INSTALLATION TECHNIQUES



INSULATING LINE POSTS:

Pin-lock or claw-style insulators can be used at lines posts. A tube insulator, secured with a 2" wide staple, can also be used. Do not drive the staple tight against the Hotcote.



JOINING:

Slide up to a 4' piece of Hotcote tubing onto the wire before attaching crimp sleeves. Use the tubing to cover the join and any possible retraction that may occur.



END POST ATTACHMENT:

Use wraparound insulators on end posts. Install insulated, underground wire to transfer electric under gates.



TENSIONING:

Install a permanent in-line strainer at the midpoint of the fence to make re-tensioning easy. Use a 4" piece of Hotcote tubing to cover crimp sleeves and exposed wire.



CORNER POST:

The corner collar fits perfectly onto wood posts to make insulating around corners fast and easy.

Safety Note: Use protective eye wear and gloves. It is essential to keep fence line clear of all debris.

Hotcote™ is a trademark of John Wall Inc. 2009